

Diagram A shows a hand pressing down on a switch. The switch is labeled 'OFF' and has a curved arrow indicating the downward motion. The switch is connected to a circuit with two parallel horizontal lines representing wires.

Diagram B illustrates the mounting of the ceiling plate. The plate is shown being attached to a wall with screws. A callout shows the wiring connections: L (Live), N (Neutral), and PE (Protective Earth). The plate is shown being pushed into the ceiling.

Diagram C shows a hand pressing down on the center of the switch. An arrow points to the right, labeled "ON", indicating the switch is being moved to the ON position.

BLA32566  
www.eglo.com